



Start



Scanner SPP slave enable



End

Zebex SPP mode. Skeniraj Start – Scanner SPP slave enable – End.
PIN koda za povezovanje je 12345678.

Unitech MS 912 SPP mode:

Start:



SPP mode:



End:

